How to use the Smartpen

Table of Contents:

- 1. Turning the Smartpen on and off
- 2. Setting up the Smartpen
- 3. Using the Smartpen: Writing and Recording
- 4. Listening to recordings
- 5. Erasing recordings

1. Turning the Smartpen On/Off:

Press the () – POWER button towards the top of the pen to turn on or off.

2. Setting up the Smartpen: (for first time use)

- 1. Open the liveScribe notebook, to the inside of the notebook cover's front page.
- 2. Look at the SETTINGS box:
 - Setting the Display:
 - Press the pen on the box of your writing hand preference: left handed or right handed.
 - > To set the Date:
 - Press the pen on the set date box until the pen shows: mm/dd/yy
 - Press the pen on the numbered boxes to set the date. For example: to first set
 the month such as August press the pen on the (zero) then (eight) number
 boxes.
 - o When you have pressed all the numbers, the date will be displayed on the pen.
 - > To set the Time:
 - o Press the pen on the set time box until the pen shows: hh:mm am/pm
 - o Press the pen on the numbered boxes to set the time, then press am or pm
 - o When you have set the time, it will be displayed on the pen.

3. Using the Smartpen: Writing and Recording

- 1. After turning the Smartpen on and setting your preferences, begin writing on the liveScribe Dot Paper notebook (similar to using any other pen).
- 2. To record what is being said while you write:
 - > (1) At the bottom of the notebook, press the pen to the record box to start recording.
 - ➤ (Option 2) Press and hold the POWER button until the pen begins recording.
 - ❖ The hours, minutes, seconds counter (00:00:00) will start counting when recording.

Note: It is best to sit toward the front of the class.

- 3. To pause the recording, press the pen to the Pause box.
 - To resume recording, press Pause box again
- 4. To stop recording, press the pen to the stop box.

4. Listening to Recordings:

Play Back Recordings:

1. Play back option #1:

To play back previous recordings taken when writing notes, press the pen on the first letter of the word you would like to listen to.

2. Play back option #2:

- At the bottom of the Dot Paper notebook, tap the pen <u>twice</u> on the middle of the pointed arrows \longleftrightarrow (the NAV PLUS).
- The pen will then speak and display: Main Menu
- ➤ Press the pen to the down pointing arrow on the NAV PLUS ↓till the pen says and displays: Paper Replay
- ➤ Press the pen to the right pointing arrow on the NAV PLUS → the Pen will display:
 Record new session
- Then press the pen on the down pointing arrow on the NAV PLUS till the pen displays: Play session
- ➤ Press the pen to the right pointing arrow—> on the NAV PLUS till the pen displays the day and time you want to listen to.
- ➤ To listen to the recording: press the pen to the right pointing arrow → on the NAV PLUS and the recording will begin playing.

3. Play back option #3:

- (for first time use) On a computer go to: www.Livescribe.com/install
 - o Download the latest software
 - o Run the Livescribe on the computer
 - o Connect the Pen's USB to the computer
 - Once the recordings and notes have transferred, click on (play) to listen

5. Erasing Recordings:

- At the bottom of the Dot Paper notebook, tap the pen <u>twice</u> on the middle of the pointed arrows (the NAV PLUS).
- The pen will then speak and display: Main Menu
- ➤ Press the pen to the down pointing arrow on the NAV PLUS ↓till the pen says and displays: Paper Replay
- ▶ Press the pen to the right pointing arrow on the NAV PLUS → the Pen will display:
 Record new session
- Then press the pen on the down pointing arrow on the NAV PLUS till the pen displays: Delete session
- ➤ Press the pen to the right pointing arrow—> on the NAV PLUS till the pen displays the day and time you want to delete
- ➤ To delete the recording: press the pen to the right pointing arrow → on the NAV PLUS